



Condensing Sequence of Operation:

The condenser heat exchanger inside the Hydronika unit is a passive device installed in the hot gas line between the compressor and the air-cooled condenser. If the heat exchanger is not sufficient to remove all of the heat required, the condenser fans will ramp up on VFD control to remove the remainder

Condenser Water Pump
Size @ 3 GPM Per Ton
Head TBD By System Used
Closed Loop System Only

Return To Pool